


Spare parts list
(5.970-616.0) Spare parts list HD 2.3/15 C Ed/ 3.0/20

Spare parts list HD 2.3/15 C Ed/ 3.0/20 (5.970-616.0)	6
10 Housing	7
20 Pump set	10
21 Cylinder head	11
100 PUMP SET HD 5/12 C (2.883-997.0)	15
22 Thrust guidance	16
30 Motor	18
40 Accessories	21
41 Hand trigger gun	22
9 Spare part set O-Ring seal 5x (2.880-296.0)	24
42 Jet pipe	25
4 Spare part set O-Ring seal 5x (2.880-296.0)	27
43 Nozzle	28
44 Nozzle	30
0 Triple jet nozzle only for replacement 0 (4.767-150.0)	32
1 Triple jet nozzle 040	33
0 Triple jet nozzle only for replacement 0 (4.767-152.0)	35
50 Electric box	37
51 Electric box	38
52 Electric box	41
200 Special tools	44
201 Tool pressure gauge	45
202 Tool valve pliers	47
203 Tool stop cock	49
204 Tool tool - extractor wobble plate	51
205 Tool valve seat excess-current	53
206 Tool mandril grooved rings -Piston D12mm	55
207 Tool sleeve grooved rings -Piston D12mm	57
208 Tool internal puller D5-8mm	59
209 Tool internal puller D=12-16mm	61
210 Tool countersupport internal puller	63
220 Tool magnetic field tester	65
230 Tool adapter System2000;M22x1,5	67
240 Tool tester electric Metratester5	69
250 Tool tester electric Metrel MI3309	71

Pos	Name	Qty.	Unit
10	Housing	1.000	ST
20	Pump set	1.000	ST
30	Motor	1.000	ST
40	Accessories	1.000	ST
50	Electric box	1.000	ST
200	Special tools	1.000	ST



10 Housing


ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.	var. information	Footnote text
	1	5.069-202.0	Device cover	1.000	ST				
Position text: 1.150-614.0									
	1	5.069-121.0	Device cover	1.000	ST	0000000000	0000000000		
Position text: 1.150-610.0 /-611.0 /-616.0									
X-X	2	6.304-099.0	Saucer-head screw M 6x 18-4.8-R2R	1.000	ST	0000000000	0000000000		
	3	6.310-053.0	Putting nut	1.000	ST	0000000000	0000000000		
	4	5.050-286.0	Frame front part	1.000	ST	0000000000	0000000000		
Position text: 1.150-610.0 / -611.0 /-616.0									
	4	5.050-206.0	Frame front part	1.000	ST				
Position text: 1.150-614.0 /									
	5	5.032-554.0	Guide	2.000	ST	0000000000	0000000000		
X	6	5.321-721.0	Hand grip	1.000	ST	0000000000	0000000000		
	7	5.050-207.0	Frame rear panel	1.000	ST	0000000000	0000000000		
	8	6.315-086.0	Rivet	4.000	ST	0000000000	0000000000		
	9	5.032-556.0	Covering cap	1.000	ST	0000000000	0000000000		
	10	2.885-007.0	Spare part set Griff	1.000	ST	0000000000	0000000000		
X-X	11	4.063-778.0	Proportioning valve chemistry	1.000	ST	0000000000	0000000000		
	12	7.311-061.0	Hexagon nut M6-LH -8-A2E ISO 4032	1.000	ST	0000000000	0000000000	(M6)	
	13	5.105-399.0	Axle	1.000	ST	0000000000	0000000000		
X-X	14	6.435-662.0	Wheel D200	2.000	ST	0000000000	0000000000		
Position text: 1.150-610.0 / -611.0 /-616.0									
	14	6.435-756.0	Wheel grey D200	2.000	ST				
Position text: 1.150-614.0 /									
	15	4.515-273.0	Spare parts set wheel cap	1.000	ST				
Position text: 1.150-614.0 /									

10 Housing

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.	var. information	Footnote text
	15	4.515-103.0	Spare parts set wheel cap	1.000	ST	0000000000	0000000000		SET OF 2 PIECES
Position text: 1.150-610.0 / -611.0 /-616.0									
X-X	16	5.044-216.0	Holder	1.000	ST	0000000000	0000000000		
X-X	17	7.303-108.0	Screw 5x20 -10.9-R2R (In6Rd)	10.000	ST	0000000000	0000000000		
	18	6.388-216.0	Hose DN 5	1.000	M	0000000000	0000000000		TO ORDER AS CUT GOODS
	19	7.312-260.0	Washer 6 -100HV-A3E ISO 7094	1.000	ST	0000000000	0000000000		
	20	5.731-652.0	Filter with weight	1.000	ST	0000000000	0000000000		
	21	5.032-555.0	Guide	2.000	ST	0000000000	0000000000		
	22	5.057-077.0	Support	2.000	ST				
Position text: 1.150-614.0 /									
X	22	5.057-062.0	Support	2.000	ST	0000000000	0000000000		
Position text: 1.150-610.0 / -611.0 /-616.0									
X-X	23	6.343-168.0	Lock washer	2.000	ST	0000000000	0000000000		
	24	7.303-046.0	Screw M6x12 -St-R3R (In6Rd)	2.000	ST	0000000000	0000000000		
	25	5.037-170.0	Hook	1.000	ST	0000000000	0000000000		
	26	5.064-217.0	Cover air inlet	1.000	ST	0000000000	0000000000		
	27	5.107-248.0	Bar shearing shackle	2.000	ST				
	29	7.311-088.0	Hexagon nut M10-8-A2K EN 1664	1.000	ST			(M10)	

20 Pump set

Pos	Name	Qty.	Unit
21	Cylinder head	1.000	ST
22	Thrust guidance	1.000	ST



21 Cylinder head

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
X	1	7.306-105.0	Screw M6x30 -8.8-R3R (In6Rd)	4.000	ST
X-X	2	6.414-252.0	Strainer	1.000	ST
	3	5.064-150.0	Suction cover	1.000	ST
X-X	4	2.884-916.0	Valve (3 Stück)	2.000	ST
X-X	5	7.303-108.0	Screw 5x20 -10.9-R2R (In6Rd)	1.000	ST
	6	5.402-727.0	Suction nipple	1.000	ST
X-X	7	6.362-481.0	O-Ring seal 14,0 x 2,0 NBR 80	1.000	ST
	8	5.064-230.0	Suction cover	1.000	ST
	9	5.550-324.0	Cylinder head	1.000	ST
X-X	10	2.884-501.0	Spare part set control piston	1.000	ST
X-X	11	4.132-007.0	Drain plug only for replacement	4.000	ST
	12	5.003-062.0	Plate	1.000	ST
	13	5.443-624.0	Nipple	1.000	ST
	14	6.362-113.0	O-Ring seal 6,0 x 2,0 NBR 70	1.000	ST
	15	7.401-908.0	Sphere 7 G300 -1.4301 DIN 5401	1.000	ST
X-X	16	6.362-175.0	O-Ring seal 5,28x 1,78	1.000	ST
	17	5.332-258.0	Helical spring	1.000	ST
X-X	18	6.362-384.0	O-Ring seal 9x1,5 - NBR 70	1.000	ST
	19	6.362-851.0	O-Ring seal 4 x 2 NBR 90	1.000	ST
X	20	5.584-091.0	Valve pin check valve	1.000	ST
	21	4.769-034.0	Nozzle insert only for replacement	1.000	ST
	22	7.306-129.0	Screw M6x40 -8.8-R3R (In6Rd)	4.000	ST
X-X	23	6.362-533.0	O-Ring seal 14,0 X 1,5-NBR 70	3.000	ST
X-X	24	4.591-038.0	Overflow valve	1.000	ST
	25	5.365-284.0	Profile gasket	1.000	ST

21 Cylinder head


ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	27	5.110-630.0	Sleeve	1.000	ST
	28	7.314-629.0	Grooved pin 2x10 -A1 ISO 8742	1.000	ST
	29	5.583-147.0	Valve screw	1.000	ST
X-X	30	6.362-468.0	O-Ring seal complete 1ST.-R.	1.000	ST
	31	4.291-014.0	Spindle complete	1.000	ST
	32	5.321-307.0	Handhold	1.000	ST
X-X	33	4.744-242.0	Switch kpl. -nur für Ersatz-	1.000	ST
Position text: 1.150-616.0					
X	33	4.744-193.0	Switch complete	1.000	ST
Position text: 1.150-610.0 /-611.0 /-614.0 /					
X-X	34	5.034-494.0	Retaining bracket	1.000	ST
X-X	35	4.401-059.0	Screw connector part	1.000	ST
	36	5.364-129.0	Flat gasket	1.000	ST
	38	6.421-320.0	Pressure gauge 0-15 MPa	1.000	ST
Position text: /1.150-611.0 / -614.0 /-616.0 /					
X-X	38	6.421-274.0	Pressure gauge	1.000	ST
Position text: /1.150-610.0					
	39	4.401-070.0	Screw connector part neutrally * AUS	1.000	ST
Position text: 1.150-616.0					
X	40	6.362-078.0	O-Ring seal 13,3x2,4	1.000	ST
Position text: 1.150-616.0					
	41	5.310-065.0	Nut	1.000	ST
Position text: 1.150-616.0					
	42	5.443-229.0	Hose stem	1.000	ST
Position text: 1.150-616.0					

21 Cylinder head

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	43	5.005-314.0	Plate suction cover	1.000	ST
X-X	100	2.883-997.0	PUMP SET HD 5/12 C	1.000	ST


100 PUMP SET HD 5/12 C (2.883-997.0)

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
X-X	10	4.132-007.0	Drain plug only for replacement	4.000	ST	0000000000	0000000000
X-X	20	4.580-311.0	Valve complete	6.000	ST	0000000000	0000000000
X	30	5.112-726.0	Bush	3.000	ST	0000000000	0000000000
X-X	40	5.115-721.0	Washer	3.000	ST	0000000000	0000000000
X-X	50	5.116-093.0	Washer	3.000	ST	0000000000	0000000000
	60	6.288-072.0	Silicon grease	1.000	ST	0000000000	0000000000
X-X	70	6.362-376.0	O-Ring seal 24,0 X 1,5	3.000	ST	0000000000	0000000000
X-X	80	6.362-384.0	O-Ring seal 9x1,5 - NBR 70	1.000	ST	0000000000	0000000000
X-X	90	6.362-533.0	O-Ring seal 14,0 X 1,5-NBR 70	3.000	ST	0000000000	0000000000
X-X	100	6.365-393.0	Oil sealing 12x20x4/6	3.000	ST	0000000000	0000000000
X-X	110	6.365-477.0	Grooved ring 12x20x5,3/2,8	6.000	ST	0000000000	0000000000



22 Thrust guidance

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
X-X	1	4.553-265.0	Piston complete only for replacement	3.000	ST
Position text: /1.150-611.0 / -614.0 /-616.0 /					
X-X	1	4.553-231.0	Piston complete only for replacement	3.000	ST
Position text: /1.150-610.0					
	2	5.061-018.0	Thrust guidance	1.000	ST
X-X	3	6.365-393.0	Oil sealing 12x20x4/6	3.000	ST
	4	7.303-047.0	Screw M6x16 -St-R3R (In6Rd)	2.000	ST
X-X	5	6.363-252.0	O-Ring seal 75,87 x 2,62	1.000	ST
X	6	5.112-726.0	Bush	3.000	ST
Position text: 1.150-610.0 / -611.0 /-616.0					
X-X	7	5.116-093.0	Washer	3.000	ST
Position text: 1.150-610.0 / -611.0 /-616.0					
X-X	8	6.365-477.0	Grooved ring 12x20x5,3/2,8	6.000	ST
Position text: 1.150-610.0 / -611.0 /-616.0					
X-X	9	6.362-376.0	O-Ring seal 24,0 X 1,5	3.000	ST
X-X	10	5.115-721.0	Washer	3.000	ST
X-X	11	6.363-402.0	O-Ring seal 11x3 NBR	3.000	ST
Position text: 1.150-614.0 /					
X-X	12	5.362-012.0	Joint ring D 12	3.000	ST
Position text: 1.150-614.0 /					
	13	5.112-825.0	Bush	3.000	ST
Position text: 1.150-614.0 /					
	14	5.116-335.0	Washer	3.000	ST
Position text: 1.150-614.0 /					
X	15	7.306-106.0	Cylinder head screw M8x70 -8.8-A2E ISO4	4.000	ST



30 Motor


ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	0	4.623-853.0	Motor complete only for replacement	1.000	ST
Position text: /1.150-610.0					
	0	4.623-858.0	Motor complete only for replacement	1.000	ST
Position text: /1.150-611.0 / -614.0 /-616.0 /					
	1	5.070-639.0	Tank oil	1.000	ST
X-X	2	5.063-195.0	Cover	1.000	ST
Position text: 1.150-610.0 /-616.0					
	2	5.064-367.0	Cover oil	1.000	ST
Position text: 1.150-611.0 /-614.0					
	3	6.303-153.0	Screw M5x15-ST-R2R (IN6RD)	1.000	ST
	4	5.064-197.0	Bearing cover B	1.000	ST
X-X	5	5.600-060.0	Blower wheel	1.000	ST
	6	5.692-081.0	Air circulation	1.000	ST
	7	6.303-320.0	Screw M 5x 20-St-R2R	4.000	ST
X	9	7.367-001.0	Radial shaft seal ring A24x37x7 -NBR DI	1.000	ST
	10	6.401-410.0	Angular contact ball bearing	1.000	ST
	11	5.802-288.0	Mounting part	2.000	ST
	12	4.120-216.0	Wobble plate	1.000	ST
Position text: /1.150-610.0					
	12	4.120-219.0	Wobble plate complete	1.000	ST
Position text: /1.150-611.0 / -614.0 /-616.0 /					
X-X	13	7.303-108.0	Screw 5x20 -10.9-R2R (In6Rd)	2.000	ST
	15	7.306-042.0	Cylinder head screw M8x25 -8.8-A2E ISO4	1.000	ST
X	17	6.288-050.0	Engine oil 1L	1.000	ST
Position text: /1.150-610.0					

30 Motor

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	17	6.288-219.0	Engine oil 1 L	1.000	ST
Position text: /1.150-611.0 / -614.0 /-616.0 /					
	18	5.767-005.0	Rubber buffer	4.000	ST
	19	7.401-128.0	Ball bearing 6202-2RS -Wälzl.St DIN 625	1.000	ST
	22	7.312-277.0	Washer 8-200HV-A2E ISO7093-1	1.000	ST
	23	7.313-004.0	Spring washer B 8-FSt-A3E DIN 127	1.000	ST

40 Accessories

Pos	Name	Qty.	Unit	var. information
41	Hand trigger gun	1.000	ST	
42	Jet pipe	1.000	ST	
43	Nozzle	1.000	ST	VERSION 1
44	Nozzle	1.000	ST	VERSION 2




41 Hand trigger gun

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
X-X	1	4.775-463.0	HAND TRIGGER GUN EASY PRESS	1.000	ST		
	2	7.303-096.0	Screw 4x22 -ST-10.9-R2R (IN6RD)	7.000	ST	0000000000	0000000000
	3	5.481-331.0	Slider	1.000	ST	0000000000	0000000000
	4	4.481-209.0	Lever complete	1.000	ST	0000000000	0000000000
	5	5.321-669.0	Handhold few	1.000	ST	0000000000	0000000000
X-X	6	4.427-215.0	Manifold complete only for replacement	1.000	ST	0000000000	0000000000
X-X	7	4.037-013.0	Hook	1.000	ST	0000000000	0000000000
X-X	8	5.110-596.0	Sleeve	1.000	ST	0000000000	0000000000
X-X	9	2.880-296.0	Spare part set O-Ring seal 5x	1.000	ST	0000000000	0000000000
X-X	10	6.390-025.0	Hose assembly DN8 max.31,5MPa 10m	1.000	ST	0000000000	0000000000
Position text: 1.150-610.0 / -611.0 /-616.0							
	10	6.391-654.0	Hose assembly standard hygiene 15m DN6 2	1.000	ST		
Position text: 1.150-614.0 /							
X-X	11	4.363-691.0	O-Ring seal kpl. -nur fuer Ersatz-	1.000	ST	0000000000	0000000000

9 Spare part set O-Ring seal 5x (2.880-296.0)

Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
10	6.362-957.0	O-Ring seal 10,0 X 2,0-EPDM 85-90	5.000	ST	0000000000	0000000000




42 Jet pipe

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.	var. information
X-X	1	4.760-663.0	Jet pipe packaged only for replacement	1.000	ST	0000000000	0000000000	
	2	7.303-129.0	Screw 4x16 -10.9-R2R (K-In6Rd)	6.000	ST	0000000000	0000000000	
	3	5.321-855.0	Handhold few jet pipe with welding bolt	1.000	ST			VERSION 2
	3	5.321-691.0	Handhold few jet pipe	1.000	ST	0000000000	0000000000	VERSION 1
X-X	4	2.880-296.0	Spare part set O-Ring seal 5x	1.000	ST	0000000000	0000000000	
X-X	5	7.401-915.0	Sphere 2,5 G20 -1.4034 DIN 5401	20.000	ST	0000000000	0000000000	
X-X	6	4.363-692.0	Grooved ring kpl. -nur fuer Ersatz-	1.000	ST	0000000000	0000000000	
X-X	7	6.362-524.0	O-Ring seal 17,0 X 1,5	1.000	ST	0000000000	0000000000	


4 Spare part set O-Ring seal 5x (2.880-296.0)

Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
10	6.362-957.0	O-Ring seal 10,0 X 2,0-EPDM 85-90	5.000	ST	0000000000	0000000000



43 Nozzle

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
	1	4.402-042.0	Screw union	1.000	ST	0000000000	0000000000
	2	6.362-460.0	O-Ring seal 14,0 X 2,5-NBR 70	1.000	ST	0000000000	0000000000
	3	5.030-528.0	Moulded part	1.000	ST	0000000000	0000000000
	4	7.401-902.0	Sphere 5 G20 -1.4034 DIN 5401	2.000	ST	0000000000	0000000000
	5	5.042-405.0	Holder	1.000	ST	0000000000	0000000000
	6		Stockpiling discontinued	1.000	ST		
X	7	6.362-480.0	O-Ring seal 12,42x 1,78	1.000	ST	0000000000	0000000000
	8	5.415-605.0	Triple jet nozzle 043	1.000	ST	0000000000	0000000000
Position text: /1.150-610.0							
	8	5.415-603.0	Triple jet nozzle 040	1.000	ST		
Position text: /1.150-611.0 / -614.0 /-616.0 /							
	9	5.311-117.0	Hexagon nut	1.000	ST	0000000000	0000000000
	10	5.037-059.0	Hook	1.000	ST	0000000000	0000000000
	11	5.394-269.0	Protection part	1.000	ST	0000000000	0000000000




44 Nozzle

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	0	4.767-152.0	Triple jet nozzle only for replacement 0	1.000	ST
Position text: 1.150-610.0 /					
X-X	0	4.767-150.0	Triple jet nozzle only for replacement 0	1.000	ST
Position text: 1.150-611.0 /-614.0 /-616.0 /					
	1	5.394-530.0	Protection part complete	1.000	ST
	2	6.343-150.0	Pin 03	1.000	ST
	3	6.362-409.0	O-Ring seal 32,0 X 1,5	1.000	ST
	4	6.362-460.0	O-Ring seal 14,0 X 2,5-NBR 70	1.000	ST
	5	5.321-884.0	Clamp	1.000	ST
	6	5.311-225.0	Nut	1.000	ST
X	7	6.362-480.0	O-Ring seal 12,42x 1,78	1.000	ST
	8	5.394-859.0	Protection part	1.000	ST
	9	7.401-902.0	Sphere 5 G20 -1.4034 DIN 5401	2.000	ST


0 Triple jet nozzle only for replacement 0 (4.767-150.0)

Pos	Name	Qty.	Unit
1	Triple jet nozzle 040	1.000	ST



1 Triple jet nozzle 040

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	2	5.394-859.0	Protection part	1.000	ST
	3	5.394-530.0	Protection part complete	1.000	ST
	4	5.311-225.0	Nut	1.000	ST
X	6	6.362-480.0	O-Ring seal 12,42x 1,78	1.000	ST
	7	6.362-460.0	O-Ring seal 14,0 X 2,5-NBR 70	1.000	ST
	8	5.415-603.0	Triple jet nozzle 040	1.000	ST
	9	6.343-150.0	Pin 03	1.000	ST
	10	6.362-409.0	O-Ring seal 32,0 X 1,5	1.000	ST
	11	7.401-902.0	Sphere 5 G20 -1.4034 DIN 5401	2.000	ST
	12	5.321-884.0	Clamp	1.000	ST




0 Triple jet nozzle only for replacement 0 (4.767-152.0)

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
	1		Distributor	1.000	ST		
	2	5.394-859.0	Protection part	1.000	ST		
	3	5.394-530.0	Protection part complete	1.000	ST		
	4	5.311-225.0	Nut	1.000	ST		
X	6	6.362-480.0	O-Ring seal 12,42x 1,78	1.000	ST		
	7	6.362-460.0	O-Ring seal 14,0 X 2,5-NBR 70	1.000	ST		
	8	5.415-605.0	Triple jet nozzle 043	1.000	ST	0000000000	0000000000
Position text: 47639850							
	9	6.343-150.0	Pin 03	1.000	ST		
	10	6.362-409.0	O-Ring seal 32,0 X 1,5	1.000	ST		
	11	7.401-902.0	Sphere 5 G20 -1.4034 DIN 5401	2.000	ST		
	12	5.321-884.0	Clamp	1.000	ST		

50 Electric box

Pos	Name	Qty.	Unit	var. information
51	Electric box	1.000	ST	VERSION 1
52	Electric box	1.000	ST	VERSION 2




51 Electric box

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
	1	5.388-512.0	Label	1.000	ST	0000000000	0000000000
	2	4.063-810.0	Cover completely	1.000	ST	0000000000	0000000000
	3	5.365-181.0	Profile gasket	1.000	ST	0000000000	0000000000
	4	5.064-242.0	Housing with bore	1.000	ST	0000000000	0000000000
	5	6.661-254.0	Capacitor 80 µF	1.000	ST	0000000000	0000000000
Position text: 1.150-610.0							
	5	6.661-274.0	Capacitor 100 µF	1.000	ST		
Position text: /1.150-611.0 / -614.0 /-616.0 /							
	6	6.650-270.0	Cable with plug GFCI	1.000	ST	0000000000	0000000000
Position text: /1.150-611.0 / -614.0 /							
	6	6.649-467.0	Cable without plug	1.000	ST		
Position text: 1.150-616.0							
	6	6.650-274.0	Cable with plug GFCI	1.000	ST	0000000000	0000000000
Position text: 1.150-610.0							
	7	7.303-031.0	Screw M4x10 -St-P2R (In6Rd)	1.000	ST	0000000000	0000000000
	8	5.263-058.0	Tensioning part	1.000	ST	0000000000	0000000000
Position text: 1.150-610.0 /-616.0							
	8	5.263-051.0	Tensioning part	1.000	ST		
Position text: 1.150-611.0 /-614.0 /							
	9	6.303-200.0	Screw 5x25-IN6RD	1.000	ST	0000000000	0000000000
	10	6.303-153.0	Screw M5x15-ST-R2R (IN6RD)	3.000	ST	0000000000	0000000000
	11	6.632-421.0	Contactor 7,5 kW / 220 V	1.000	ST	0000000000	0000000000
Position text: 1.150-610.0							
	11	6.632-422.0	Contactor 7,5 kW / 115 V	1.000	ST	0000000000	0000000000
Position text: 1.150-611.0 / -614.0 /-616.0							

51 Electric box

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
	12	5.048-251.0	Plate	1.000	ST	0000000000	0000000000
	13	6.630-049.0	Cap	1.000	ST	0000000000	0000000000
X	14	6.631-196.0	Motor protecting switch	1.000	ST	0000000000	0000000000
	16	5.043-050.0	Holder for capacitor	1.000	ST		
X-X	17	7.303-037.0	Screw M5x10 -St-P2R (In6Rd)	1.000	ST		
X-X	18	7.312-054.0	Washer 12-A2 ISO 7090	1.000	ST		
	19	7.311-071.0	Hexagon nut M12-A2-70 ISO 4032	1.000	ST		



52 Electric box

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	1	5.388-512.0	Label	1.000	ST
	2	4.744-229.0	Switch kpl.	1.000	ST
Position text: 1.150-610.0 /-611.0 /-614.0 /					
X-X	3	6.632-412.0	Switch 14 A	1.000	ST
	4	5.263-085.0	Tensioning part	1.000	ST
	5	5.365-181.0	Profile gasket	1.000	ST
	6	5.048-251.0	Plate	1.000	ST
	7	6.632-422.0	Contactor 7,5 kW / 115 V	1.000	ST
Position text: 1.150-611.0 /-614.0 /					
	7	6.632-421.0	Contactor 7,5 kW / 220 V	1.000	ST
Position text: 1.150-610.0					
	8	5.061-598.0	Housing electric control box	1.000	ST
	9	6.661-254.0	Capacitor 80 µF	1.000	ST
Position text: 1.150-610.0					
	9	6.661-274.0	Capacitor 100 µF	1.000	ST
Position text: 1.150-611.0 /-614.0 /					
	10	6.303-153.0	Screw M5x15-ST-R2R (IN6RD)	3.000	ST
X-X	11	7.312-054.0	Washer 12-A2 ISO 7090	1.000	ST
	12	7.311-071.0	Hexagon nut M12-A2-70 ISO 4032	1.000	ST
	13	5.043-050.0	Holder for capacitor	1.000	ST
X-X	14	7.303-037.0	Screw M5x10 -St-P2R (In6Rd)	1.000	ST
	15	5.263-058.0	Tensioning part	1.000	ST
Position text: 1.150-610.0					
	15	5.263-051.0	Tensioning part	1.000	ST
Position text: 1.150-611.0 /-614.0 /					

52 Electric box

ET/VT (spare/wear parts)	Pos	Material #	Name	Qty.	Unit
	16	6.303-200.0	Screw 5x25-IN6RD	1.000	ST
	17	6.650-274.0	Cable with plug GFCI	1.000	ST
Position text: 1.150-610.0					
	17	6.650-270.0	Cable with plug GFCI	1.000	ST
Position text: 1.150-611.0 /-614.0 /					
	18	7.303-031.0	Screw M4x10 -St-P2R (In6Rd)	1.000	ST