


Spare parts list
(5.970-095.0) Spare parts list separator

Spare parts list separator (5.970-095.0)

Pos	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
10	Add-on kit separator	1.000	ST	0000000000	0000000000



10 Add-on kit separator

Pos	Material #	Name	Qty.	Unit	from ser.nr.	up to ser.nr.
1	6.363-227.0	Seal	1.000	ST	0000000000	0000000000
2	6.901-050.0	Suction hose only for replacement metal	1.000	ST	0000000000	0000000000
3	6.902-121.0	Suction tube aluminium only for replacem	1.000	ST	0000000000	0000000000
4	6.394-399.0	Cover complete	1.000	ST	0000000000	0000000000
Position text: / 2.863-161.0 / 2.863-139.0 /2.863-183.0						
4	6.394-510.0	Cover complete	1.000	ST	0000000000	0000000000
Position text: /2.863-161.0						
5	6.904-328.0	Filter bag cloth complete	1.000	ST	0000000000	0000000000
Position text: /2.863-161.0						