


PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
PIECE PARTS 1.0					
1	9001-1090	Cover top part (K380M-Griff)f.Ersa.	1		
/ 1.141-301.0 / -302.0 / -313.0/ -314.0 / -316.0 / -317.0					
2	9001-1110	Cover top part replacement K390-GRIFF	1		
/ 1.141-401.0 / -402.0 / -413.0/ -414.0 / -415.0					
5	7303-0960	Screw 4x22 -ST-10.9-R2R (IN6RD)	6		
6	9036-3660	Cover bottom part	1		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
PUMP SET - Cylinder Head 2.1					
1	5731-6090	Filter with weight	1		
2	6388-2160	Hose DN 5	1		
3	9001-1030	Spare part set nipple chemistry	1		
4	9001-1040	Spare parts set control head	1		
5	7311-5690	Square nut M4 -04-A2E DIN 562	1		
6	9081-4180	Form seal	1		
7	9036-3220	Supporting disk	3		
8	6362-8750	Grooved ring	3		
9	9001-1100	Moulded part complete	1		
10	9001-1050	Spare parts set cylinder head	1		
11	9036-4440	Sleeve - Version 2	1		
12	9039-1170	Cover - Version 2	1		
12	2889-0750	Spare part set pressure cap - Version 1	1		
13	7306-0420	Cylinder head screw M8x25 -8.8-A2E ISO4	4		
14	9047-0260	Spring	1		
15	9001-1490	Spare parts set valve (3 Pack)	1		
16	9001-1060	Joining piece	1		
17	9001-1070	Cage complete	1		
18	9001-1080	Injector complete	1		
19	6389-8700	Connection 3/4"	1		
20	9001-1870	Inlet Elbow	1		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
PUMP SET - Thrust Guidance 2.2					
2	9047-0230	Spring	3		
3	9001-1020	Piston complete (3 Pack)	1		
4	9081-3730	O-Ring seal 70x2-NBR70	1		
5	9001-1010	Thrust guidance	1		
6	6964-0260	Seal	1		
7	7306-0420	Cylinder head screw M8x25 -8.8-A2E ISO4	4		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
MOTOR 3.0					
0	9001-0930	Motor	1		
1	6964-0900	Housing	1		
2	7304-3950	Hexagonal head screw M8x16-8.8-A2E ISO	1		
3	9039-1020	Blower wheel	1		
4	6964-0920	Viscous oil 50ml	1		
5	6964-0960	End Plate	1		
6	9078-0040	Rotary Shaft Seal	1		
7	7401-0100	Ball bearing 6303 -St DIN 625	1		
8	9086-1530	Cylinder Head Complete	4		
9	9086-1690	Wobble plate screw M8x16	1		
10	9001-3000	Swash plate	1		
11	7312-2330	Serrated lock washer A8.4-FSt-A3E DIN67	1		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ACCESSORIES - Trigger Gun 4.1					
0	4775-2640	Trigger Gun	1		
/ 1.141-301.0					
1	5321-5120	Handhold few	1		
2	6303-1220	M4.2x13 DIN 7981 Torx T15 Pan HD HI/LO	9		
3	5481-1890	Lever	1		
4	4427-1780	Manifolds	1		
5	2880-2960	Spare part set O-Ring seal 5x-Kaercher	1		
6	7362-5020	O-Ring seal 2,8x1,6-NBR 70 DIN 3770	1		
7	5107-1470	Bar	1		
8	5582-0580	Valve disc	1		
9	5332-1570	Helical spring	1		
10	6362-4790	O-Ring seal 7,59X 2,62	1		
11	4481-1050	Lever	1		
12	5314-0820	Pin	1		
13	5110-5390	Sleeve	1		
14	5028-9050	Pipe	1		
15	5332-3490	Pressure spring	1		
16	6363-1150	O-Ring seal complete 1ST.-R.	1		
17	6390-2040	High pressure hose neutrally 6/12MPa 40G	1		
/ 1.141-301.0					



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)

Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ACCESSORIES - Trigger Gun 4.2					
0	9001-1250	Trigger Gun	1		
/ 1.994-830.0					
1	9036-4080	365 Trigger Gun Handles (Casing)	1		
2	6964-0440	Moulded part	1		
3	9011-4020	Bush completely	1		
4	6964-0020	Spring	1		
5	5481-1590	Lever	1		
6	6303-1220	M4.2x13 DIN 7981 Torx T15 Pan HD HI/LO	8		
7	9011-3970	Pipe	1		
8	6362-8980	Gasket 7x2 NBR90	1		
9	5031-0680	Joining Piece	1		
10	5332-3490	Pressure spring	1		
11	2880-2960	Spare part set O-Ring seal 5x-Kaercher	1		
12	9082-0570	HP Hose	1		



R J Bowers Distributors

2003 Harrison Ave
Rockford IL 61104


E-mail: service@rjbowers.com

Web: www.rjbowers.com

(815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)

Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ACCESSORIES - Trigger Gun 4.3					
0	2641-2020	Pistol-M replacement packaged V1.1 RM K2	1		
1	5037-1370	Clamp	1		
2	5332-4640	Pressure spring	1		
3	6363-1980	O-Ring seal 6x2 90 shore PUR	1		
4	6390-4630	High pressure hose 9/16MPa	1		
5	2880-2960	Spare part set O-Ring seal 5x-Kaercher	1		




R J Bowers Distributors

2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)

Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ACCESSORIES - Jet Pipe 4.4					
1	5762-3310	Carrier brushes	1		
2	2640-5890	Brush lengthwise	1		
3	4760-5340	VPS K3 0287	1		
4	2640-7290	O-Ring seal set	4		
5	4760-2770	Lance	1		
6	4763-9860	Rotor Nozzle 033	1		
7	2640-9070	Brush Best	1		


/ 1.141-413.0



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)


Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ACCESSORIES - Water Filter 4.5					
1	4730-0590	Water filter complete	1		
2	5363-5450	Seal	1		
3	5363-3360	Seal	1		
4	5731-0500	Water filter	1		
5	6389-8700	Connection 3/4"	1		
6		Stockpiling discontinued	1		
7	5310-1180	Nut	1		
8	5364-1290	Flat gasket	1		
9	4730-0980	Water filter complete packaged	1		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584

PARTS BREAKDOWN FOR K380 (1.141-316.0)

Location	PN	DESCRIPTION	QTY	SERIAL #	
				FROM	TO
ELECTRICAL CONTROL BOX 5.0					
1	9001-1000	Cover electric box complete	1		
2	7303-0310	Screw M4x10 -St-P2R (In6Rd)	1		
3	9085-0230	Capacitor 20mikroF H=70	1		
4	9036-3480	Housing electric box	1		
5	9081-4080	Gasket 19x34x2.62	1		
6	9048-0110	Wire protecting sleeve	1		
7	9086-1530	Cylinder Head Complete	2		
8	9085-0310	Switch two-pole	1		
9	9084-0740	Cable with plug *RA	1		
/ 1.141-414.0					
9	9084-0640	Cable with plug	1		
9	9084-0700	Cable with plug *CH	1		
/ 1.141-302.0 / -402.0					
9	9084-0550	Cable with plug	1		
/ 1.141-301.0 / -313.0 / -401.0 / -413.0					
15	9036-3510	Switch Knob	1		



R J Bowers Distributors
 2003 Harrison Ave
 Rockford IL 61104
 E-mail: service@rjbowers.com
 Web: www.rjbowers.com
 (815) 399-8839 (800) 383-6584